

Air Interface Protocol

Transmit Protocol : TCP, UDP, MQTT, SMS

BLE Accessory Support : Yes

Scheduled Timing/angle/distance Report : Report position and status at preset intervals

External Power Status Alarm : Report when external power is disconnected

Low Power Alarm : Report when backup battery is low

Speeding Alarm : Report when speed exceed the pre-set value

Towing Alarm : From internal 6-axis accelerometer

Remote Control : Remote output control

Network Signal Jamming Detection : Report network jamming

Data Roaming Control : Avoid additional data consumption

Driving Behavior Monitoring : Aggressive driving behavior detection, e.g. harsh braking and acceleration

Crash Detection : Accident data collection for reconstruction and analysis